




# Forget a network on your iPhone, iPad, or iPod touch

1. Go to Settings > Wi-Fi.
2. Tap ⓘ next to the Wi-Fi network that you want your device to forget.
3. Tap Forget This Network, then tap Forget to confirm.



# To forget a network that you've joined before but aren't currently using

1. Go to Settings > Wi-Fi.
2. Tap Edit in the corner of the screen to see the networks known to your device.
3. Take either of these actions:
  - Tap the delete button , then tap Delete.
  - Or tap the info button  next to the network, tap Forget This Network, then tap Forget to confirm.